

Operations Manual



Automated Fuel Maintenance System

FTI-10A & FTI-20A



FUEL TECHNOLOGIES INTERNATIONAL LLC

Replacement Manuals Available on Website: www.fueltechnologiesinternational.com

03/01/2011 – Fuel Technologies – FTI-10A and FTI-20A

Controller Programming And Operating Instructions

Contents

<i>Introduction / Overview</i> -----	<i>Page 2</i>
<i>Controller Set-Up with the Touch Screen</i> -----	<i>Page 3</i>
<i>Default Start-Up Screen</i> -----	<i>Page 4</i>
<i>Menu Screen</i> -----	<i>Page 5</i>
<i>Company Information Screen</i> -----	<i>Page 6</i>
<i>Clock Adjust Screen</i> -----	<i>Page 7</i>
<i>Select the Day of the Week to Run & Number of Tanks in your System</i> -----	<i>Page 8</i>
<i>Set-Up Tank Filtering Start Times & Filtering Run Time Hours</i> -----	<i>Page 9</i>
<i>Set-Up Delays for: Pump, Valves, Alarms, & Flow</i> -----	<i>Page 10</i>
<i>Main Operations Screen</i> -----	<i>Page 11</i>
<i>How to Cancel System Alarms</i> -----	<i>Page 11</i>
<i>Alarm Message Descriptions</i> -----	<i>Page 12</i>
<i>How to Run In Manual and Auto Modes</i> -----	<i>Page 13</i>

FTI - Fuel Maintenance Systems

Introduction

This manual assumes the system is installed and ready for operation. If the system has not yet been installed, please refer to the Installation manual for instructions.

Overview

FTI Fuel Monitoring and Maintenance Systems are designed for ease of use. Once installed, the system will operate automatically to the schedule you program into it. The schedule should be determined by your specific needs, fuel and tank conditions, weather, etc. and can be changed at any time. ***It is recommended to filter approximately 20% of the tank per week.*** (If you are not sure what your optimum schedule might be, your FTI representative can assist you).

Your FTI system will maintain all data input by you, such as the time, run time hours, and number of tanks, etc. ***This will last for up to 100 hours without power. After that, the data will have to be re-entered.***

If the system is in auto mode and stopped for any reason, it will resume the schedule when the interruption is complete. You can also switch to manual mode at any time. The system will resume with the preprogrammed schedule when put back into auto mode.

Depending on the condition of the fuel to be maintained, you may initially be changing filters more frequently than expected. Your FTI system will stop operation and signal you when filters are full. It will also let you know which particular filter should be changed, and will resume the program when restarted after the filter is replaced. As the fuel quality progressively increases, you will notice a dramatic drop in filter usage.

In cases of ***Serious Contamination***, it is recommended that you have your ***Fuel Polished*** prior to initial use of your FTI system. Since the FTI system is proactive, continued use prevents the fuel from deteriorating again and maintains a healthier environment to protect both the fuel and tank.

INSTALLATION PRECAUTIONS:

IF POWER TO THE FTI CONTROL PANEL IS TO BE TURNED OFF AFTER IT IS INSTALLED, THEN THE INSTALLER SHALL PROVIDE FOR THERMAL EXPANSION PROTECTION.

ALL MANUAL BALL VALVES SHALL REMAIN OPEN. THIS WILL ALLOW FUEL THERMAL EXPANSION TO FLOW BACK TO THE FUEL TANK.

THE FTI CONTROL PANEL WILL AUTOMATICALLY OPEN ALL ELECTRICALLY CONNECTED VALVES WHEN THE FTI PRESSURE SWITCH GAUGE REACHES 45 PSI. THIS WILL OPEN AND CLOSE ALL TANK VALVES FOR 15 SECONDS ONE TANK AT A TIME.


THIS FEATURE OPERATES AUTOMATICALLY ONLY WHEN POWER IS ON AND THE CONTROL PANEL IS SET TO AUTO OR MANUAL OFF MODES.

THE OPENING AND CLOSING OF VALVES WILL ACTIVATE 6 TIMES IN 24 HOURS, AFTER 6 TIMES THE CONTROL PANEL WILL GO INTO OVER PRESSURE ALARM.

THIS IS A PRECAUTION TO ALERT MANAGEMENT THAT YOU HAVE A THERMAL EXPANSION PROBLEM AND IT SHOULD BE ADDRESSED.

FTI WILL NOT BE RESPONSIBLE FOR ANY THERMAL EXPANSION DAMAGE DUE TO EXCESSIVE PRESSURE.

Controller Set-Up with the Touch Screen




Once the Fuel Management System is installed, you're ready to program the controller.

When you apply power to the system, the display will go through a boot up sequence, and the screen above will appear for a few seconds. ***DO NOT PUSH ANY BUTTONS ON THIS SCREEN.***

IF YOU DO PUSH A BUTTON ON THIS SCREEN, TURN THE POWER OFF AND THEN BACK ON TO RE-BOOT THE CONTROLLER.

Wait until this screen above changes to the default *Main Operations Screen* (next page).

Default Start-Up Screen




The screen above is the *Main Operations Screen*.

From this screen You Can:

1. Go to the Menu Screen.
2. Switch from Auto Mode to Manual Mode.
3. Reset All Alarms.
4. Turn system On & Off in Manual Mode.
5. The **Next Tank Button** & the **Previous Tank Button** only appear when the number of tanks selected is greater than one.

To Set-Up the Controller Press the Menu Screen Button.

Menu Screen



The screen above will appear.

This is the screen to access all system filtering selections.

From the left hand column you can:


1. Adjust the clock.
2. Set-up which days of the week to run, & the number of tanks (1-4) plumbed to the FTI system.
3. Set-up daily filtering start times, & filtering run time hours.
4. Set-up delays for: Pump to Start, Valves to Close, Alarms to Trip, & Low Flow Alarm to Trip.
5. Access the main operations screen, from where you can manually turn system on and off.

From the right hand column you can:

1. Re-calibrate the screen.
2. Increase the contrast on the screen.
3. Decrease the contrast on the screen
4. Clean the screen.
5. Look up Fuel Technologies company information, and access Modbus setup button.

From the Menu Screen Press the Company Information Button

Company Information Screen



The screen above is the *Company Information Screen*.


This is where you can look up Fuel Technologies International LLC:

1. Mailing Address
2. Website information
3. Modbus Communications setup.

(This button is on all system screens but is only active when the **Optional Modbus Communications** system is purchased)

Next Press the Menu Screen Button, Then the Clock Adjust Button.

Clock Adjust Screen





The screen above will appear.


1. Start on the left column under **Day Adjust**; press the **Increase** or **Decrease Button** until the correct day appears.
2. Do the same for the **Hour Adjust** and the **Minute Adjust**.
3. The above screen shows Friday, 1:25 PM

***When Completed Press the Menu Screen Button,
Then the: Set-up Day of Week to Run & No. of Tanks in System Button***

Select Day of the Week to Run & Number of Tanks in your System




1. First decide the number of tanks plumbed to the system (1-4). This system is capable of filtering up to four tanks.
2. To Set-up the number of Tanks, touch or press the number in the box. The keyboard screen below will appear.
3. Then press the number 1, 2, 3 or 4, and then the **large arrow button**.  (same as enter key)
If you select the wrong number use the BSP button to back space (erases numbers selected)
4. Then you need to decide what days of the week you want your system to run, & which tank you want to filter on each day.
5. To select the day of the week to run, touch or press the number in the box. Then the **large arrow button**.
6. The example screen above shows a 4 Tank System, with a filtering schedule as follows:
Tank 1 on Monday, Tank 2 on Wednesday, Tank 3 on Thursday, & Tank 4 on Friday.



Press the Next >>> Button

Set-Up Tank Filtering Start Times & Filtering Run Time Hours



The screen above will appear.


1. First decide which day & time of day to start the filtering process.
(To adjust, touch or press the number in the box as described on page 8)
2. You can select only one start time for (Sunday), one start time for (Monday – Friday), and one start time for (Saturday)
3. The clock settings are (1-23) hours.
 - A. Above Example: Set Saturday start time 8 = 8AM
 - B. Above Example: Set Mon.-Fri. start time 13 = 1:00 PM

Then proceed to Set-up the Filtering Run Time in Hours:

1. On the same screen you can select the run time hours to filter your fuel. (The recommended is 20% of the tank per week.)
2. Example: 20% of a 20,000 Gallon Tank = 4000 gallons.
3. Then take the pump size: 20 gallons a minute pump x 60 minutes = 1200 gallons an hour.
4. Then divide 1200 (gallons an hour) into 4000 gallons (20% of tank) = 3.33 hours per week.
5. Round up to 4 hours per week.
6. The screen above will only show the number of tanks in your system that you selected in the set-up Numbers of tanks screen (Tank 1, Tank 2, Tank 3, or Tank 4).
 - A. Above Example: Above screen shows a 4-tank system, filtering all 4 tanks for 4 hours ea.

When Completed Press the Next Button

Set-up Delays for: Pump, Valves, Alarms and Flow



The screen above will appear.

If you have special circumstances that require you to *delay the pump to start*, *delay the valves to close* (multi-tank systems), *delay the alarms from going off*, or *change the low flow alarm delay*, then continue with this step, if not skip forward to the bottom of this page.


Here you can delay:

1. The pump from turning on by 1-90 seconds.
(When using ACTUATED BALL VALVES, the pump will need to be delayed allowing valves to open before pump is turned on. Adjust the pump delay start seconds to the ball valve opening time.)
2. The solenoid or electric actuated ball valves from closing by 1-90 seconds. (multi-tank systems)
3. The alarms from going off by 1-90 seconds.
4. The correct default setting for lines 1, 2, and 3 is 1.
5. The low flow alarm (1-6 minutes – default is 3 minutes) this is a Flow or No Flow alarm.
6. (To adjust all settings, touch or press the number in the box as described on page 8)
(The low flow alarm task is to protect the pump in case it has lost its prime. The pump will run for the time selected and then it will shut off and sound an alarm to notify maintenance personal the fuel supply line is dry)

When Completed Press the Main Screen Button

Main Operations Screen

1. Here you can select **Auto Mode** or **Manual Mode** by pressing the **Auto/Manual Button**. Auto mode will run your system automatically by the **Start & Run Times** you have entered.
2. In **Manual Mode** the system will stand idle. (Put in Manual Mode for servicing the filters)
3. You can turn the system on and off in **Manual Mode**. Press the **Manual Start Button** to turn on. Press the same button now labeled **Manual Stop** to turn off.
4. When you set-up more than one tank there will be extra buttons labeled **Next Tank (1-4)** and **Previous Tank (1-4)**, use these buttons to scroll to tanks 2, 3, & 4.



How to Cancel System Alarms

First read the Alarm Description on the screen, and then push the **Alarm Reset Button** to stop the alarm and reset the system. (Alarm description will appear in the MANUAL MODE SELECTED box above)

Note: The system will switch to **Manual Mode** for safety reasons when alarm status is reset. Be sure the system is in **Manual Mode**, and is not running, before attempting any maintenance operations. This is to avoid leakage or other possible hazards. Once maintenance has been performed (such as changing filters), turn system on manually to check for leaks. Then reset to **Auto Mode** and resume the scheduled program.

You Have Now Completed the Controller Set-Up

ALARM MESSAGE DESCRIPTIONS

If a problem is detected in the following areas, the system will stop filtering, display the appropriate alarm message on the screen, and will sound an audible alarm to alert the operator. The alarm consists of a sequence of steady high-pitched beeping sounds that continue until the operator pushes the reset button and corrects the problem.

Alarm Status

Description

100 Mesh Strainer Blocked
Change Filter & Reset

Vacuum / Strainer Gauge

Action: Check inlet strainer and supply line valves.

10-Micron Filter Blocked
Change Filter & Reset

10 Micron Gauge

Action: Change 10 micron filter

3-Micron Filter Blocked
Change Filter & Reset

3 Micron Gauge

Action: Change 3 micron filter

1-Micron Filter Blocked
Change Filter & Reset

1 Micron Gauge

Action: Change 1 micron filter

Over Pressure
Check Valves & Reset

System Pressure caused by blockage in the system or return line.

Possible Causes:

1. Failed Solenoid valve, Ball valve, Relief valve, or Check valve.
2. Auto Pressure Relief:

The FTI control panel will open & close all electrically actuated valves 6 times in 24 hours, and then go into over pressure alarm. The opening of valves lasts for 15 seconds. The alarm is to notify maintenance that there is a line pressure problem that needs attention.. This feature is to purge thermal expansion pressure build up in the lines. The program will continually open & close valves even after it goes into alarm mode.

- Action:**
1. Cancel error, restart system and locate reason for high pressure.
 2. Eliminate thermal expansion with relief valve.

High Water Level
Drain and Reset

Water Level Sensor

Action: Drain water from water separators.

System Leak
Repair Leak & Reset

System Leak, Leakage has occurred somewhere within the cabinet area.

Action: Locate and correct leaks in the FTI cabinet.

Generator Running
Filtering Off

This is a 24V DC dry contact to be used with Gen Set Run Relay. It will shut off the filtration system while the generator is running. (See wiring Diagram for electrical connection).

Action: *This contact is only used when FTI system is sharing the Same Fuel supply line as the Gen Set. It will turn FTI system off When the Gen Set turns on. (Do not schedule filtration system run Times on the same day of Gen Set testing).*

Pump Overload
Reset over-load & RESET

This will occur if pump/motor is over heated or over loaded.

Action: Find cause and repair.

1. Push the touch screen reset and then;
2. Push the reset button on the overload inside of the control panel.

Low Flow Alarm

This alarm will trip if the fuel flow stops while the pump is running.

Action: Find out why pump prime was lost and repair.

RUNNING MANUAL MODE

To switch to ***Manual Mode***, press the ***Auto / Manual Button*** until the display reads:

MANUAL MODE SELECTED
TANK 1 FILTERING OFF

Once in ***Manual Mode***, pressing the ***Manual Start Button*** will turn the system ***ON*** and it will begin to pump fuel through the system. Pressing the same button now labeled ***Manual Stop Button*** will turn the system ***OFF***.

If you have a multiple tank system and want to isolate a particular tank, press the ***Next Tank (1-4) Button*** until the display reads the tank number you wish to process. Then press the ***Manual Start Button*** to start the system.

RUNNING AUTO MODE

To switch to Auto Mode, press the ***Auto / Manual Button*** until the display reads:

AUTO MODE SELECTED
AUTO MODE – FILTERING OFF

The controller will now execute the schedule programmed earlier by you.

NOTE: IF POWER IS INTERRUPTED FOR ANY REASON THE PREVIOUS MODE SETTING (AUTO OR MANUAL) WILL COME BACK ON. IF IN AUTO MODE, AND THE POWER GOES OFF FOR ANY LENGTH OF TIME DURING THE SCHEDULED RUN TIME, THE SYSTEM WILL RUN THE PROGRAMMED SCHEDULE WHEN POWER IS RESUMED.

INTERRUPTING AUTO MODE

To stop the system while running in ***AUTO MODE***, press the ***Auto / Manual Button*** until the screen says ***“Manual”***. (This should be done before performing maintenance tasks, such as changing filters, draining separators, etc.) To resume operation, press the ***Auto / Manual Button*** until ***“Auto”*** appears on the display. The system will now resume with the preprogrammed tasks.